



YDS-150

Firmware Update Guide

EN

Thank you for choosing a Yamaha product.

This document explains how to update the firmware of the YDS-150 and the update history.

For details of the major new functions and operations, refer to YDS-150-related documents on the following website:

<https://download.yamaha.com>

■ Special Notices

- When you execute this update program, any settings you have made will be overwritten with the corresponding defaults.
- Please save your important data onto the YDS Controller app before updating the firmware of the YDS-150.
- This updater is to be used at the user's own risk.
- DO NOT power off or disconnect the cable from the product during the updating process. The YDS-150 may be damaged.
- DO NOT remove your PC from the product during the updating process. The YDS-150 may become inoperable.
- If the update fails, and the YDS-150 still does not operate correctly even after you execute the update once again, please contact your Yamaha dealer.
- This software and documentation are the exclusive copyrights of Yamaha Corporation.
- Reproducing or modifying all or parts of this software or its documentation without permission is strictly prohibited.
- The company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Included Files

This folder contains the following files:

- | | |
|--------------------------------------|--------------------------|
| • yds-150_en_update_guide_v***.pdf | this document (PDF file) |
| • the "YDS-100_001_instdat.bin" file | the update program |

Required Items

- PC (Windows or Mac)

Confirming the Current Version

You can confirm the current version of your YDS-150 via the YDS Controller app. For details on the YDS Controller app, refer to the Owner's Manual of the YDS-150 or the following web site.

https://www.yamaha.com/2/yds_series/

NOTICE

To confirm the current version of your YDS-150, you will need to connect with the smart device having the installed YDS Controller app. The current version cannot be confirmed from only the YDS-150.

Updating Procedure

NOTICE

Make sure to save your important data onto the YDS Controller app before updating the firmware of the YDS-150.

1. After downloading, extract the archived file, and then copy the "****.bin" file to the root directory of your PC.
2. Connect your YDS-150 to your PC via the USB cable.
3. While holding the [Fn] button of your YDS-150, press the Standby/On button to turn the power on. The power lamp lights in red, and the LED screen displays "Upd." Also, your YDS-150 is recognized as a removable disk on your PC.
4. Copy the update file from your PC to the root directory of the folder recognized as a removable disk. The file name is "YDS-100_001_inst.dat.bin."
5. Press the [Fn] button of your YDS-150. The LED screen displays "rdy."
6. Press the [Fn] button again to start the update process. The LED screen displays "---" and the Bluetooth lamp flashes in yellow. The update may take several minutes.
7. When the update is completed, the LED screen displays "End." Also, the power lamp is lit red.
8. Turn off the power of your YDS-150.
9. Confirm that the version is the latest according to the steps of "Confirming the Current Version" in this document.

NOTICE

After updating the firmware, delete the pairing settings for this product from the smart device on which the YDS Controller app is installed, and then set the pairing again.

This completes the update process.

Main Enhancements

[V1.00 → V1.10]

- Added the MIDI controller function.
- Solved some minor errors.

©2023 Yamaha Corporation
Published 04/2023 YJ-A0