Please make sure to use the appropriate versions of firmware and software, referring to the following compatibility charts. Using an unsupported combination may result in malfunction.

ご使用の際は下紀対応表を参照のうえ、互換性のあるバージョンでご使用ください。互換性のないバージョンを組み合わせて使った場合、誤動作の原因になることがあります。

Control PLUS ProVisionaire Kiosk	Power Amplifiers				VO Interfaces					Digital Mixers					Audio Processros			
	XMV8140 XMV4280		NXAMP4X2MK2 NXAMP4X1MK2	NXAMP4x4MK2	PC412-DI PC406-D	Rio3224-D Rio1608-D Ri8-D Ro8-D	Rio3224-D2 Rio1608-D2	Tio1608-D2		EXi8 EXo8	DSP-RX DSP-RX-EX DSP-R10 CSD-R7	DM7 DM7 Compact	DM3 DM3 Standard	QL1 QL5 CL1 CL3 CL5	TF5 TF3 TF1 TF-RACK		MTX3 MTX5-D MRX7-D	RM-CR
V1.0.0	V3.10 or later	V3.10 or later	LOAD4_23 or later	LOAD3_03 or later	V1.0.2 or later	V4.10 or later	V1.10 or later	V2.00 or later	V1.02 or later	V3.10 or later	V5.02 or later	V1.01 or later	V1.01 or later	V4.10 or later	V3.51 or later	V1.01 or later	V3.10 or later	V1.0.1 or later

	Powered Speakers			Microphones			MusicCast Devices				Video Switchers (IDK)				
Control PLUS ProVisionaire Kiosl	•	DZR315-D DZR15-D DZR12-D DZR10-D	DXS18XLF-D DXS15XLF-D	RM-CG		RM-WAP-8 RM-WAP-16	WXC-50 WXA-50		CD-NT670 CD-NT670D		MSD-502 MSD-701	MSD-S52 MSD-S71	MSD-6203/Dan MSD-6204/Dan MSD-6206/Dan MSD-6208/Dan	MSD-402	MSD-701UHD
V1.0.0	V1.0.0 or later	V1.1.3 or later	V1.1.3 or later	V1.0.1 or later	V1.2.0 or later	V1.9.3 or later	Please use the latest firmware.	Ver1.16 or later	Please use the latest firmware.	Please use the latest firmware.	V1.00 or later	V1.00 or later	V1.02 or later	V1.22 or later	V1.05 or later